



Installation Instructions

FAIRPLAY ZX

PLAYER

Hardware Included:

- (2) 50 1/2" Aluminum Rails (2) 2" Bolts
- (2) 39 1/2" Aluminum Rail

Side Curtain:

Mount one 50 1/2" aluminum rails on either side of the car roof by drilling 1/8" diameter holes thru the rail and roof. Use 1/8" pop rivets and put approximately 4 rivets in each side (Figure 1.1).



Figure 1.1

The front of the rail should be approximately 1/2" from the front post holding the windshield. The "C" opening should be facing "inward and down." Approximately 12" to 16" of the aluminum rail will be visible toward the front of the car.

